



AquaFire®

Installation Guidelines
and Best Practices

AquaFire Series

AWA2-20-50 / AWA2-40-100 / AWA2-60-150

Experience the original water vapor flames and dazzling orange glow of Aquafire with our pioneering series of inserts.



Aquafire Series

3 Sizes, AWA2-20-50 **20"** / AWA2-40-100 **40"** / AWA2-60-150 **60"** .




Shown: AWA2-40-100 40"

- Units can be ganged together to create continuous ribbons of flames up to 20 feet (240") .
- 20 hours of run time or can be direct plumbed for unlimited run time (direct plumb kit sold separately).
- Adjust the flame size (height) and speed (intensity) to enjoy 8 to 12" inch flames.
- Control via button on device or integrate with in-room automation via the dry port contact.
- Easy Flush Mount Install.
- Air Intake through the lid.
- Alternate Hidden Air Intake (from below).
- Internal UV-C Lighting sanitizes water & vapor.

Quick Start Guide


1. Installing Into Its Site-Built Enclosure

- 1** Remove the top plate.
- 2** Connect the 24V power adapter (located on the back side of the unit).
- 3** Install Aquafire into its housing, as shown in example below.
- 4** Reinstall the top plate of the fireplace and install is complete.




2. Filling Aquafire with Automatic Pump

- 1** When the water tank is empty, you will see the lights blinking and you will hear small beeps.
- 2** Connect the fill tube to the water connector and press and hold the “B1” button for 5 seconds.
- 3** The filling will start automatically and will end automatically when the water tank is full.



3. Connect Direct Plumb Kit (Sold Separately)

- 1** Connect a suitable reducer to the water network. (Reducer = water network tube dimensions to 1/4")
- 2** Connect the 1/4" PEX pipe to the Aquafire Direct Plumb Kit (sold separately).
- 3** The filling will start automatically and will end automatically when the water tank is full.



4. Pairing the Remote Control

- 1** Press and hold the Power button on the unit for 5 seconds or until the button will begins flashing.
- 2** Press any button on the remote, you will hear a beep.
- 3** Beep confirms the control is paired to the unit.



Preliminary Planning Information

Aquafire Pro water vapor fireplace inserts have been designed to be extremely easy to install, simple to operate, and easy to maintain. When designing your fireplace, feel free to send your plans in for review and suggestions by our professional design staff.


Considerations:

- Accessibility to electricity and 1/4" water line, similar to ice maker in fridge.
- Recessed into wall, sitting proud of a wall or completely free-standing?
- If light cast upwards to ceiling is undesirable, consider recessing into the wall for a traditional hearth appearance. (we advise to create a 'light trap'. see **Light Trap** page for details)
- Determine decorative materials and finishes you expect to use. Since there is no heat, there are virtually no limitations.
- Plan to make it easy to remove fireplace insert should maintenance or repairs become necessary.
- Avoid or prevent air currents from doors, windows, and existing HVAC system which affect flame quality.

Installation:

Prepare the housing for your fireplace insert(s) and make sure the cutout has sharp corners (not rounded) and dimensions are exactly as specified. These dimensions are critical because the modules are suspended on flanges that span the opening. Too small, and fireplace will not fit, too large of opening, and fireplace insert will look sloppy or may even fall through the opening. Using the built in 'lifting loops', suspend the **Aquafire** into the cutout after plugging in electric power converter(s) and connecting the 1/4" waterline if direct plumb kit is installed. If not, simply fill tank using tap water via the integrated pumping system once installed into enclosure.


That's it!— the installation is complete. Now start your fireplace and enjoy an extraordinary fireplace experience every day of the year!



**World's most advanced
water vapor fireplace
technology.**


Fireplace Specs and Cutout Dimensions

Aquafire Dimensions




20" AWA2-20-50:

Power: 60 W (Standard wall receptacle)
Tank Capacity: 2.0 Liters / Run Time 20 Hours
Direct Plumbed: 1/4" water line
Weight: 29 lbs / Crated Weight 53 lbs



40" AWA2-40-100:

Power: 120 W (Standard wall receptacle)
Tank Capacity: 4.0 Liters / Run Time 20 Hours
Direct Plumbed: 1/4" water line
Weight: 58 lbs / Crated Weight 90 lbs



60" AWA2-60-150:

Power: 180 W (Standard wall receptacle)
Tank Capacity: 6.5 Liters / Run Time 20 Hours
Direct Plumbed: 1/4" water line
Weight: 89 lbs / Crated Weight 123 lbs


Cutout Dimensions

SIZE		W	D	H*
20"	AWA2-20-50:	20 1/4" x	12 1/4" x	12"
40"	AWA2-40-100:	40 1/4" x	12 1/4" x	12"
60"	AWA2-60-150:	60 1/4" x	12 1/4" x	12"

*Direct Plumb Kit (optional) requires additional 2" of Height dimension.

Note:

Cutout dimensions are critical! Fireplace inserts are suspended in cutout opening from the attached flanges so be sure to measure carefully!



Up to 20 Feet of Flame

Connect and combine fireplace inserts together to create up to 20 feet of continuous flame that can be controlled by a single remote.




Up to 20 Feet (240 Inches)





Recommended Enclosure Dimensions

When you have your design schematic or working drawings, it's a good idea to get a review by an Aquafire professional. We are here to help! sales@aquafire.com



Avoid using reflective materials (tile, stone, HPL, etc) on the top inside of the light trap. A darker, non-reflective finish in the firebox will accentuate the flame effect and limit light bleed.




A **minimum of 6"** clearance on each side and/or a **blind corner** will help to reduce horizontal light reflection.

For optimal results, utilize an open-ended hearth design.

Installing Aquafire Insert

Installing Insert into custom enclosure

SIDE VIEW




120v/60 Hz (min 12-amp) outlet

Optional ¼ PE water supply line

Air Intake through toe kick,
Optional if top vents are covered

FRONT VIEW



Drop-in install

Aquafire inserts are designed to drop in to an enclosure and hang from the lid's flanges, allowing for easy install and adequate airflow underneath the unit.



Cutout Dimensions

SIZE		W	D	H*
20"	AWA2-20-50:	20 ¼"	12 ¼"	12"
40"	AWA2-40-100:	40 ¼"	12 ¼"	12"
60"	AWA 2-60-150:	60 ¼"	12 ¼"	12"

*Direct Plumb Kit (optional) requires additional 2" of Height dimension.

Note:

Cutout dimensions are critical! Fireplace inserts are suspended in cutout opening from the attached flanges so be sure to measure carefully!



24v power adapter
can be stored under
the unit.



Enclosure Design Guidelines

Types of Enclosures


Type 1: Recessed Hearth




Type 2: Open Hearth (against wall)




Type 3: Coffee Table(Fire Pit)



Type 4: Room Divider Floating Wall



Type 5: Glass Enclosure



Type 6: Dining Table



Type 7: Retrofit (traditional)



Type 8: Wall Hung




Type 9: 3-Sided Island



Enclosure Design Guidelines


Light Path Comparison

The light from the Aquafire may shine past the top of the enclosure and illuminate the room ceiling. If you do not desire additional illumination you will need to create a light trap or design your enclosure accordingly. Reference the chart below to determine the recommended enclosure dimensions to trap the light within the enclosure. It is recommended to choose enclosure dimensions that fall along the diagonal line on the chart.



Side Light Considerations

When designing your enclosure, it is important to take into consideration horizontal light bleed. Installing Aquafire too close to either side of the enclosure can cause the horizontal light path to reflect onto the side walls of the enclosure, resulting in an undesirable effect. It is recommended to leave **at least 6 inches** of space between Aquafire and the side walls of the enclosure. For best results, we recommend either an open-ended enclosure design or the use of a blind corner to hide an potential light bleed.




Enclosure Design Guidelines

Air Flow Best Practices

SIDE VIEW

SINGLE-SIDED HEARTH



Air currents


Avoid blowing air currents from HVAC units directly toward the Aquafire insert. Direct air currents can prevent vapor from rising vertically as designed and limit the flame height.

Air intake requirements

Aquafire inserts require at least 50 square inches of air intake within the enclosure for every 20 inches of unit length. This is achieved by venting through either the top lid or, if covered, via a toe kick beneath the enclosure.


Air vents

Air vents are situated atop the insert to enable airflow when the device is placed within an enclosure. Should there be a preference for a decorative top or media obstructing these vents, the enclosure design needs to facilitate adequate airflow through the sides or bottom.



Maintenance and Cleaning Guidelines

Hard Water Guidelines



For best results, descale your fireplace every three months or more frequently if you live in an area with hard water.

3.5 to 8.5 Grains Per Gallon, Ideal is 7.0 (moderately hard)

- Hard may produce scaling, shorten transducer life, and require more frequent cleaning.
- If water hardness needs to be adjusted, consult local water conditioning professional.
- Water that is too soft will have reduced flame effect.

Reverse Osmosis is not recommended, it removes all minerals and vapor flame effect will be greatly diminished.

For complete descaling instruction visit www.aquafire.com/cleaning



Contact Us

sales@aquafire.com

www.aquafire.com

(877) 888-4260

Aquafire® is a registered trademark of Lumina Products Inc,
the North American Distribution Partner for A|Fire Design

 www.aquafire.com