

Loctite® Power Grab® Express Heavy Duty Installation Instructions:

ACOUSTIC PANELS (Fabric, Image, & AcoustiColor®)
ACOUSTICOLOR SHAPES
AUDIMUTE STRATA®
ACOUSTIWOOD®, ACOUSTISTONE®, ACOUSTIFELT™

Step 1: Apply 2" diameter dabs of adhesive on a panel, no more than 2' apart.



Step 2: Press firmly into place and you're done!

