

Audimute Strata® Installation Instructions:

AUDIMUTE STRATA TAPE (Included) & LOCTITE® POWER GRAB® EXPRESS HEAVY DUTY (Not Included)

Audimute Strata consists of pieces in multiple sizes. To install, you will just need the included Audimute Strata Tape and Loctite Power Grab Express Heavy Duty adhesive. Use a retractable utility knife and a T-square to cut the pieces if needed for an exact fit. Curve, Slant, and Sawtooth styles should be installed with the pieces mindfully applied to achieve the desired look.



Step 1: Apply the tape vertically to the wall, about 9" - 16" apart.



Step 2: Starting from where the lowest row will be, apply adhesive between the tape, using just enough to add Audimute Strata pieces before the adhesive dries.



Step 3: Add pieces to create the first row, then work your way up the wall by adding more adhesive and pieces, cutting the pieces if needed. Please note, pressing down too hard from the top of the pieces when stacking them may result in less total sqft.

