



1. Measure and mark the appropriate mounting locations on the side wall of each cabinet. We recommend placing the brackets 3" in from the front and back of the cabinet.
  2. Use a coping saw, oscillating multi-tool or router to cut a 2½" wide x ½" deep mounting channel for the bracket to rest in.
- ⚠ Caution: Do not cut into any of the factory structural supports in the corners of the cabinets.**
3. Place the bracket into the mounting channel on each cabinet.
  4. Prior to setting the top in place, run a bead of high-quality silicone adhesive down the center of each bracket.