

## Keyhole Plate Hanging Method Installation Instructions: FABRIC & ACOUSTIC IMAGE PANELS



Keyhole plate mounting is a very secure method to attach panels to walls or an angled section of a ceiling. The keyhole plates come preattached to the panels.




**Items needed:** 4 included included screws for the keyhole plates, a level, a measuring tape, a pencil, and a Phillips head screwdriver.



**Step 1:** Position the panel on the wall where you want the top of the panel to be. Then, use a level and draw a line on the wall across the top of the panel with a pencil.



**Step 2:** Measure 5 1/4" down from the line and make another level line.



**Step 3:** Measure the distance between the keyholes on the panels.



**Step 4:** Using the measurements between the keyholes, mark the locations on the wall with a pencil starting on the level line created in Step 2. Then, screw the double headed screws into the marked locations.



**Step 5:** Hang the panel by sliding the keyhole plates over the double headed screws in the wall.

