

POST WRAP



KEYLINK

INSTALLATION GUIDE



RECOMMENDED TOOLS

- Safety Glasses
- Tape Measure & Pencil
- Power Drill
- Circular Saw

WHAT'S INCLUDED

- (4) Post Wrap
- (2) Pan Head Screws

1. *These directions are only a guide and may not address every situation.*
2. *Always wear proper safety equipment while assembling and installing.*
3. *The installer should obtain all required building permits and follow all installation procedures in accordance with applicable building code requirements.*
4. *Keylink, Inc. shall not be held liable for improper or unsafe installations.*
5. *Applying paint, other than Keylink's touch up paint, will void your warranty.*
6. *To ensure proper coverage by our warranty please visit our website and complete the warranty form and mail to: Keylink, 110 Peters Road, New Holland, PA 17557*





WARNING: This product can expose you to chemicals including Quartz (crystalline silica), which is known to the State of California to cause cancer, and Hexavalent Chromium, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

1 CUT POST WRAP PANELS

Measure the height of the existing Posts to be covered.

On a Non-Abrasive surface; carefully cut the wrap panels to the correct lengths.

■ **Cutting Tip:** Be sure to use a **fine-tooth blade approved for cutting aluminum** and rest panels on a piece of **non-abrasive material** to protect from scratches.






2 INSTALL POST WRAP PANELS

Snap together panels in pairs then finalize the connection around the post by connecting the pairs.

When snapping both pairs around the Post; ensure the panels are square before finalizing the connection.



NOTE: If the posts are less than 5- 1/2" square; use blocks to expand the sides out to the proper widths (5-1/2"), at the Top, Bottom. If you want to prepare for a future railing installation; a 12" block or shim should be placed 32" to 44" from the bottom of the Post; for extra support.



3 INSTALL POST TRIM

Connect Trim pieces around the Top and Bottom of the Post.

Use two Pan Head Screws placed on opposite sides; just below the edge of the Trim in order to hold them in place.



110 Peters Road, New Holland, PA 17557

KEYLINKONLINE.COM